

CLEANING & CARE OF LAMINATE

ROUTINE CARE

- Never flood the floor with water or cleaner. Laminate flooring can expand if excessive water is used while cleaning. After mopping, use a clean dry cloth to wipe the floor of any excess water.
- Difficult stains such as coffee or tea can be removed using a mild household cleaner/detergent and a soft bristle brush, repeating as necessary. If a stain persists, use a paste of baking soda and water and apply with a soft bristled brush.
- For difficult stains, use nail polish remover that contains acetone or alcohol.
- Hair, textile, and food dyes can cause permanent stains. If dye should happen to spill, wipe it up immediately with dishwashing detergent or an all-purpose cleaner.

PREVENTATIVE CARE

- To prevent indentations, use floor protectors on chairs and other furniture.
- Do not use soap-based detergents or mop-and-shine products as they may leave a dull film on your floor.
- Do not use abrasive cleaners, steel wool, or scouring powder, which can all scratch the laminate surface.
- Do not use a wax polish on your laminate floor.
- Never place pots or dishes directly from the oven or a hot surface onto an unprotected laminate surface.